

GEKO™
Xpedition

Quick Start Guide

Full HD GPS-enabled Standalone
Smart Dash Cam

Disclaimer

1. Please follow the set-up and usage instructions in the print material that came with this Dashboard Camera (dash cam) product.
2. You should not set/install this dash cam at a place that would obstruct or reduce a driver's view, make sure your usage comply with pertinent vehicle codes of your state, province, territory or country.
3. You should post the required notices of recordation to occupants inside the vehicle, if voices or other information/signal pertaining to in-vehicle activities will be recorded.
4. You should not change the dash cam's setting or mode of operation or when the vehicle is in motion.
5. The optional driving warning signals, including any visual or audible reminding signals, should not replace your decision-making and judgment that are needed for the proper operation of the vehicle.
6. You should not leave the dash cam in a visible spot when no one is inside the vehicle, to avoid attracting break-ins to steal the unit, or other property.
7. You should avoid extended exposure of the dash cam to direct sunlight or extreme temperatures (either high or low temperature) which tend to degrade or damage the unit and its normal functionality.
8. You should examine, check and/or verify the dash cam at least every six (6) months, including the associated memory cards, to ensure the video reception and recording are working properly. For each use, you should verify that the dash cam unit, the visible lights and the audible sounds are working normally. If there are signs of non-operation or mal-function, you should immediately seek to replace the product and check to see if the product is covered under any applicable warranty.
9. The dash cam unit may have additional functionality, such as transmission and recordation of audible or GPS signal or other identification information. If you have privacy concerns about these functions, make sure you follow the instruction to disable these functions.
10. You should use the dash cam unit in the way it is intended. You should not use the dash cam unit in a way that would be illegal or that tends to physically damage the unit, or tends to cause danger to the safe operation of the vehicle or the occupants.

/ HELLO

Thank you for choosing GEKO for your dash cam needs. In this guide we will show you how to properly setup and install your GEKO Xpedition.

/ Accessories



GEKO Xpedition



Snapshot Remote



Docking Bracket



Memory Card



Cable



Power Adapter




Windshield Sticker Mount



Manual

/ GEKO Xpedition Product Overview




Status LED

Recording	GREEN
Recording / Memory Card Error	OFF
Snapshot	GREEN Flash
Wi-Fi Error	RED
GPS Error	YELLOW
Snapshot Remote Error	BLUE

Power LED

Low Power 10%	RED Flash
Low Power 20%	RED
Charging	BLUE Flash
Full	GREEN
Upgrading Firmware	GREEN Flash

/ How to Install GEKO Xpedition in Vehicle



Prepare your GEKO Xpedition for installation:

1. Hold device and docking bracket with both hands and mount GEKO Xpedition securely to docking bracket as shown in image above.
2. Insert a microSD memory card into the microSD slot located on the back of the GEKO Xpedition as indicated in the image shown under the Product Overview section of this manual.

(Note: SDHC Class 10 or above micro SD memory cards are recommended for use with GEKO Xpedition)

3. Press memory card in until you feel a click and the card is fully inserted into the slot.
4. For your safety and proper installation of camera make sure your vehicles engine is off during the installation process of your GEKO Xpedition.
5. Once ready to install make sure to clean the windshield to ensure secure installation of your GEKO Xpedition.
6. Once area has been cleaned and a safe installation spot has been chosen (make sure chosen location does not block or obscure a driver's view when driving as described in the How to Choose Installation Location of this manual). Install camera at the desired location.
7. Once camera has been installed and mounted, connect the USB power cable provided with your GEKO Xpedition to the Power Adapter.
8. You are now ready to start recording your journey.

(Note: The GEKO Xpedition will automatically begin recording once engine starts, and will stop recording 20 seconds after engine has been shut down.)

/ How to Connect to GEKO Xpedition

1. Download Mobile App

The GEKO Xpedition Apps are available from the Apple® App Store and Android® Market. Search for "Xpedition", and download it.

2. Connect to Device via Wi-Fi Connection

Make sure your smartphone's Wi-Fi is switched on and search for your GEKO Xpedition. It will appear as SSID "Xpedition_XXXXXX". Once you have selected it, you will be asked for a connection password (Default: 12345678). Once connected, open your Xpedition App and search for your GEKO Xpedition.

Note: It should appear automatically in the list.


For Android users:

Make sure your smartphone's Wi-Fi is switched on. Open the App and find your GEKO Xpedition in the list. Once selected you should be connected.

3. Snapshot Remote Pairing

Power on the GEKO Xpedition. Once it has powered on, switch on the Snapshot Remote. You should see a blue LED light flashing during the auto-pairing process. After it has successfully paired, the Snapshot Remote LED will stop flashing and the GEKO Xpedition should beep upon pressing the Snapshot Remote button.

/ How to Choose Installation Location



1. Do not install device in a location that will interfere with driver visibility or safety.

2. Do not install device on, near or in the path of any area where airbags maybe present or may deploy. If you are uncertain of air bag placement for your car, please contact your vehicle manufacturer for details.
3. Do not install device on sun control film (window tint) to prevent any potential damage.
4. Do not hang power cable across windshield. Install/route power cable where it will not interfere with driver and is not on, near or in the path of any airbags as shown in image above.
5. Install device in a location near the rearview mirror with the best view, and in a location where it is not obstructing or distracting driver visibility.
6. Install in a location where the GEKO Xpedition will not be affected by the sun film (window tint) or any other electronic device which may cause potential issues.

Note: The manufacturer is not liable for any injury or death which may be caused by deployment of airbag.

/ Frequently Asked Questions

- 1 Q: My GEKO Xpedition will not record.

A: Make sure you are using a SDHC compatible microSD memory card (it is recommended you use a Class 10 rated or higher card). Also make sure the card you are using has enough space, or try formatting to the card to see if that resolves the issue.

- 2 Q: My GEKO Xpedition is heating up a lot.

A: Heat is normal during normal operation. Normal operating temperatures are between -20° C - 70° C. (Note: Our GEKO Xpedition meets and exceeds product specifications, and has passed extensive testing from a third party authority.)

- 3 Q: My device has stopped responding.

A: If device has stopped responding to all commands, use a paperclip to reset your device. The reset button is located on the back of the unit as shown in the overview image.

- 4 Q: What is the maximum capacity microSD card that can be used?

A: The maximum recommended capacity is 32GB.

(Note: This is not a Plug & Play device. Please do not remove microSD card during operation of device. Please make sure to power off unit before inserting or removing memory card.)

- 5 Q: How do I change the recording settings?

A: It is recommended that any change of recording settings or shutdown delay settings be done via the Xpedition App. Once the Xpedition App has been launched and connected to your GEKO Xpedition, click on the GEAR icon located at the top right of the App and then click Device Settings to make changes.

- 6 Q: What's seamless loop recording?

A: This feature is to ensure continuous recording. The feature will begin to overwrite previous footage in order to continue recording. (Note: Files/footage which are lock-protected or emergency footage will not be overwritten).

Note: GEKO is not responsible for the loss, corruption, or accidental deletion of footage, and is in no way liable for any damages which may arise from failure of the device or data loss.